

PoweringUp


Before Powering Up

- ⚠⚠⚠ Make sure that the arms are in a proper location before powering up. Upon boot up, the arms will try to go back to their initial position, if not in proper location it could hurt you.



PowerUp

- Press the power button, and the robot will boot automatically



□□ #4
□ Yangfan He □□ 3 □ 2024 08:15:00
□ Yangfan He □□ 23 □ 2024 13:44:02